

RB26DETT ECU Pinout



WIRED BY
Wiring Specialties
 www.WIRINGSPECIALTIES.COM

Pin #	Color	Description	Pin #	Color	Description
1		IGNITION SIGNAL #1	39		
2		IGNITION SIGNAL #5	40		
3		IGNITION SIGNAL #3	41		CAM ANGLE SENSOR (120 DEGREE SIG.)
4		Idle Air Control Valve	42		CRANK ANGLE SENSOR (1 DEGREE SIG.)
5		ENGINE A/T CONTROL INPUT SIGNAL (BT1)	43		Start Signal
6		SUB ELECTRICAL FAN RELAY	44		NEUTRAL SWITCH
7		Tach Signal	45		IGNITION SWITCH (IGN)
8			46		A/C SWITCH
9		A/C RELAY	47		(CHK) CHECK (DIAGNOSIS ACTIVATION)
10		GROUND	48		THROTTLE SENSOR POWER SUPPLY
11		IGNITION SIGNAL #6	49		CONTROL UNIT POWER SUPPLY
12		IGNITION SIGNAL #2	50		GROUND (CONTROL UNIT)
13		IGNITION SIGNAL #4	51		CAM ANGLE SENSOR (120 DEGREE)
14		ENGINE A/T CONTROL INPUT SIGNAL (BT2)	52		CRANK ANGLE SENSOR (1 DEGREE)
15		ENGINE A/T CONTROL INPUT SIGNAL (BT3)	53		VEHICLE SPEED SENSOR
16		ECCS RELAY	54		THROTTLE VALVE SWITCH
17			55		Rear Oxygen Sensor Signal
18		FUEL PUMP RELAY	56		THROTTLE SENSOR INPUT
19		POWER STEERING SWITCH	57		THROTTLE VALVE SWITCH
20		GROUND	58		BATTERY POWER SUPPLY
21		(RX) RECEIVE	59		CONTROL UNIT POWER SUPPLY
22		(TX) TRANSMIT	60		GROUND (CONTROL UNIT)
23		Knock Sensor (cyl 1-3)	101		INJECTOR #1
24		Knock Sensor (cyl 4-6)	102		
25		Boost solenoid	103		INJECTOR #3
26		AIF FLOW METER GROUND	104		FUEL PUMP TERMINAL VOLTAGE OUTPUT 1
27		AIR FLOW METER INTAKE AIR SIGNAL	105		INJECTOR #2
28		Coolant Temp Sensor	106		FUEL PUMP TERMINAL VOLTAGE OUTPUT 2
29		Front Oxygen Sensor Signal	107		INJECTOR GROUND
30		SENSOR GROUND (THROTTLE SENSOR)	108		INJECTOR GROUND
31		CLOCK (SYNCRONIZATION SIGNAL)	109		INJECTOR POWER SUPPLY
32		Check Engine Light	110		INJECTOR #5
33			111		
34		REAR MAF Sensor Ground	112		INJECTOR #6
35		REAR MAF Sensor Signal/ MAP Sensor Input	113		
36		IAT Sensor Input (removed)	114		INJECTOR #4
37			115		
38		TPS Signal	116		INJECTOR GROUND

RB26DETT ECU Pinout